

Quick Guide to PlantPen Operation

1. To Switch on: Hold the Set key for one second.
2. To Scroll Through a Menu: Use the Menu key.
3. To Select a Menu Option: Use the Set key.
4. To Get into a Submenu: Scroll through the main menu and find your option based on the cursor (>). Use the Set key to make your selection and to get into a submenu.
5. To Scroll Through a Submenu: Use the Menu key.
6. To Return from a Submenu: Scroll through the submenu to the >Return option. Use the Set key to make your selection and to return to the Main Menu.
7. To Switch off: Scroll to the >Turn Off command in the Main Menu and click the Set key. (The PlantPen switches off automatically after five minutes without a command).

Detailed, step-by-step instructions for the PlantPen operation are in your owner's Manual.

Quick Guide to PlantPen Operation

Main Menu:

- PRI/NDVI**
- Data**
- Setting**
- Turn Off**

Main Menu with SubMenus:

- PRI/NDVI**
- Data**
 - Browse*
 - Erase*
 - Return*
- Setting**
 - Calibration*
 - Multiplication*
 - Average*
 - Piezo*
 - Return*
- Turn Off**